

ET/ip

PS/LI/Note Techn. 84-1
27.7.1984

A BEAM DESTINATION READ-OUT FOR BH3/BH4


E. Tanke

1. Introduction

For the control and acquisition of the bending magnets BH3/BH4 an in-crate microprocessor was installed, running an assembler program burnt in EPROM. Since the microprocessor changes the magnet currents (i.e. the beam destination) in real time, a tool which helps solving possible problems during operation becomes vital. For this purpose we designed a CAMAC module allowing real time read-out of the beam destination for each of the two bending magnets.

11. 13.6.81 Radom


FIG. 1



TITLE	BH3/BH4 beam destination	SCALE	5 25.017	LE 1 0 1 3	3
OLD NUMBER			3		



FIG. 2



EDITIONS
1/13.6.81

TITLE	SCALE	525.017	LE	201	3
BH3/BH4 beam destination		OLD NUMBER			



1). 18.6.81 / ka.doku


FIG. 3

DESSIN, RUGOSITÉ, TOLÉRANCES
SELON NORMES ISO



Projection européenne
First angle projection

Ce dessin ne peut être utilisé à des fins commerciales sans autorisation écrite.
This drawing may not be used for commercial purposes without written authorisation.



<p><i>BH3/4 beam destination</i></p>	<p>ECHELLE SCALE 1:1</p>	DESSINÉ	
		CONTROLÉ	
		REMPLECE	
		REMPLECE PAR	
		RÉDUCTION	
<p>ORGANISATION EUROPÉENNE POUR LA RECHERCHE NUCLÉAIRE EUROPEAN ORGANIZATION FOR NUCLEAR RESEARCH CERN-DIV :</p>	<p>TÉL. : (022) 83 81 11 TELEX: GENEVE 2 36 98</p>	<p>525.017 LE 301.4</p>	
			INDICE

2. Description

The assembler program expects the module to be in station 9 of crate 52. After obtaining the beam destination by reading a timing module, this information is written into the module in station 9 by using the CAMAC function F16A0. A decoder will give X and Q on receiving this function and the "VALID X" LED will light up (Fig. 1). In order to have the beam destination written into the coder, the CAMAC function F16A0 is used to clock the right buffer. The coder will then process the input pattern and drive the appropriate LEDs.

Whenever an incorrect pattern is found on the coder's input, the "ERROR" LED will light up.

Figures 2 and 3 show the detailed electronics and the front panel, respectively.

Remark: Whenever BH3 is set to zero, the BH3 "0" LED will light up. If no action is undertaken on BH4, all BH4 LEDs will be off.

Distribution:

Linac Group
PS Operation